



# Fan Guard Installation Instructions

P/N - 3" 76040-1, 4" 76040-2

1. Install the "Fan Guard" on the exhaust side of the fan (as close to the fan as possible).
2. Drill a 7/16" hole in the side of the inlet pipe, below the fan (locate within 36" of the fan guard).
3. Thread the hole with a 1/4"NPT tapered pipe tap.
4. Apply pipe tape or sealant to the elbow fitting thread and screw into the tapped hole. Tighten to final orientation, open end up.
5. Cut the tubing and the insulation to the desired length. Insulation should be a little longer than the tubing to cover the elbows. **DO NOT** have any U bends in the tubing that would trap water!
6. Push each end of the tubing and insulation over the barbed elbows.
7. Install a cap at the top of the exhaust pipe or provide another means to prevent leaves or other debris from falling into the exhaust pipe.

