



HI-PERDRAIN™ INSTRUCTIONS

Contents:

- HI-PERDRAIN ST
- Access port plug (sold separately)
- Sump cover (sold separately)

Directions:

- 1) Peel protective paper off both sides of the sump cover's clear acrylic disk. Note the tapped-from side of the sump cover; this side should be on the bottom of the cover when installed.
- 2) Thread the HI-PERDRAIN ST into the sump cover from below / bottom side. Secure with the lock nut supplied with the HI-PERDRAIN ST.
- 3) Install the sump cover. Be sure the drain does not get in the way of a pump or anything in the sump. For best results, seal the assembly to the floor or slab air tight (RadonAway PGS or similar sealant).
- 4) Snap the access port plug into the 5" hole in the sump cover.
- 5) Should any debris foul the float ball in the HI-PERDRAIN ST, pry the inlet grate off with a flat-head screwdriver, remove the ball with a spoon, and clean the drain. Re-install the ball and the inlet grate.

