



HI-PERDRAIN™ ST RETROFIT INSTRUCTIONS

Contents:

- HI-PERDRAIN™ ST SUMP DRAIN
- HI-PERDRAIN™ RF ADAPTER

Directions:

- 1) Cut a 3 ½" diameter hole in the existing or retrofit sump cover* using a RadonAway hole saw (28282-32) or equivalent
- 2) Completely thread HI-PERDRAIN ST into RF ADAPTER from below / bottom side. Secure with the lock nut supplied with the HI-PERDRAIN ST.
- 3) Install the HI-PERDRAIN ST Sump Drain & RF ADAPTER into the cover as shown using a water-proof sealant or glue (for best results glue the assembly air-tight to the cover using Gorilla glue or similar product).
- 4) Should any debris foul the float ball in the HI-PERDRAIN ST Sump Drain, pry the inlet grate off with a flat-head screwdriver, remove the ball with a spoon, and clean the drain. Re-install the ball and the inlet grate.

